




Advanced Water Filters  
Where Technology and Water Combine  
Perfect Water Technologies, Inc.  
Copyright © 2004

*Advanced Water Filters*

**Check Valve & Flow  
Restrictor Change  
Instructions**



**Tap Master® Check Valve & Flow Restrictor Change Instructions**Tools Required

Towel

1. Clear away a workspace under the sink near the location of the Tap Master.
2. Turn off the water feeding the Tap Master, by closing the ball valve located on the water line, or by closing angle-stop feed water valve clockwise. To close the angle-stop, turn clockwise. If present, the angle-stop will be located on the wall under the kitchen sink in close proximity to the Tap Master. Either method will work. Close the valve leading to the refrigerator if your Tap Master was ordered with a refrigerator connection kit.
3. Close the reserve tank valve located on top of the reserve tank. When closed the blue handle will perpendicular to the water line.
4. Depressurize the system. Flip up the handle on the RO sink spigot so that it locks into place, and dispenses water until it no longer flows. If you have successfully shut off the water this should occur within a few seconds. If water still continues to flow, repeat steps 2 & 3. The system is now depressurized; continue to leave to RO sink spigot handle in the open position.
5. Slowly and gently pull the Tap Master off of its mounting clips from the bottom up. Lay it on a towel.
6. Remove the tubes from the bottom of the membrane-housing "push-pull" fittings – to do this depress the collet ring to the fitting body with the thumb and forefinger while simultaneously pulling on the tubing. Some mild resistance to pulling out the tubing is normal. Removing the tubing will be

impossible without first fully depressurized the Tap Master as described above.

7. Unscrew the white check valve, and replace with the new white check valve. Unscrew the grey flow restrictor valve and replace with the new grey flow restrictor valve.
8. Reinsert the tube end about a ¼" into the fittings "push-pull" fitting then pull back gently to ensure a snug fit.
9. Remount the Tap Master, and **SLOWLY** open the main water line to the Tap Master. Open valve to refrigerator. *Failure to repressurize slowly may result in system damage.*
10. Remove the tube from the tank valve and check the flow. It should be a thin stream or steady trickle. It may take 20 minutes for water to begin flowing. Replace tubing in tank valve. Open tank valve. Close the RO sink spigot, and allow 3 hours for the reserve tank to refill, and then drain completely. **System must be flushed prior to use.**

